

United VMS 9.2.7

Admin Center User Guide

Latitude

© 2024 Teledyne FLIR LLC All rights reserved worldwide. No parts of this document, in whole or in part, may be copied, photocopied, translated, or transmitted to any electronic medium or machine-readable form without the prior written permission of Teledyne FLIR LLC

Names and marks appearing on the products herein are either registered trademarks or trademarks of Teledyne FLIR LLC and/or its subsidiaries. All other trademarks, trade names, or company names referenced herein are used for identification only and are the property of their respective owners.

This product is protected by patents, design patents, patents pending, or design patents pending. The contents of this document are subject to change.

For additional information visit www.flir.com or write to Teledyne FLIR LLC

Teledyne FLIR LLC
6769 Hollister Avenue
Goleta, CA 93117

Phone:
888.747.FLIR (888.747.3547)
International: +1.805.964.9797

Support:
<https://www.flir.com/support/>
For technical assistance, contact us at +1.888.388.3577
or visit the Service and Support page at www.flir.com/security.

Document History

Version	Date	Comment
1	December 2024	9.2.7 GA Release

Table of Contents

1. Introduction	1
1.1 Scope	1
1.2 Finding What You Need	1
1.3 Intended Audience	1
1.4 More Information – Help System	2
1.5 About this File	3
2. FLIR United VMS Latitude System Overview and Main Components	4
2.1 Servers	4
2.2 Latitude Clients - Admin Center, Control Center and Web Client	5
2.3 Security for Your FLIR United VMS Latitude System	6
2.3.1 System - System Security	8
2.3.2 System - Edge Security	10
3. Licensing your VMS	13
4. Using the Quick Configuration Wizard (QCW)	19
4.1 QCW – Prerequisites	19
4.2 Starting the QCW	20
4.3 QCW - Global Settings	21
4.4 QCW – Archivers	22
4.5 QCW – Adding a Network	24
4.6 QCW – Configuring Archiver Storage	26
4.7 QCW – Discovery	28
4.7.1 Automatic Discovery	30
4.7.1.1 Discovering FLIR Cameras and Encoders	32
4.7.2 Manual Discovery	32
4.7.3 Adding Generic Cameras	34
4.8 QCW - Attach Cameras to Archiver	35
4.9 QCW – Quality	37
4.10 Accessing Applications from the Sidebar	38
4.11 Accessing Wizards from the Sidebar	39
5. Setting up Cameras in the Latitude System	40
5.1 Individual Camera Settings – the Camera Parameter Screens	41
5.1.1 General Tab	42
5.1.2 Video Settings Tab	42
5.1.3 Picture Settings Tab	43
5.1.4 Recording Settings Tab	44
5.1.5 Edge Recording Tab	45

Table of Contents

5.1.6	Linked Tab	46
5.1.7	PTZ Configuration Tab	47
5.1.7.1	PTZ Controls	49
5.1.8	Motion Detection Tab	51
5.1.9	Quick View Tab	55
5.1.10	Privacy Masking Tab	55
5.1.11	Actions Tab	55
5.2	Setting up Groups of Cameras	56
5.2.1	Using 'Copy Configuration'	56
6.	Setting up Other Entities	58
6.1	Microphones and Speakers	58
6.1.1	Define a Microphone or Speaker	58
6.1.2	Link a microphone and/or speaker to a camera	59
7.	Logical Configuration	61
7.1	Enterprises and Sites	61
7.2	Sequences	62
8.	Setting up Specialized Servers	64
8.1	Web Server	64
8.2	Transcoder Server	65
8.3	Gateway Server	66
8.4	Case Builder Server	67
9.	Alarm Management	68
9.1	Set up Alarm Types	69
9.2	Set up How to Trigger an Alarm	73
10.	User Management	74
10.1	Define User Groups and Users	75
10.1.1	Access Rights	76
10.1.2	Privileges	77
10.2	Inheritance	78
11.	APPENDIX 1 - 'How to' Configuration Information	79
11.1	Tips and Tricks using the Latitude Interface	79
11.1.1	Foldaway Bars	80
11.1.2	Using 'Switch View' or clicking a node	80
11.1.3	Dialogs Display When Items are Selected	81
11.1.4	Search Bar Highlight mode	82
11.2	Define Coverages from the System Settings View	82

Table of Contents

11.3	Create a Coverage in System Settings	82
11.4	Choose an Existing Coverage from the Camera Screen	83
11.5	Define a New Coverage from the Camera Screen	83
11.6	Create a Video Profile (using System Settings View)	84
11.7	Video Profile Parameters	84
11.8	Video Profile	85
11.9	Create Schedules (using System Settings View)	85
11.10	Create a New Schedule	87
11.11	Configure Actions and Events	88
11.12	Bind Encoders and Cameras	89
11.13	System-Wide Events	90
11.14	TLS - Setting up Encryption to/from Web Clients	91
12.	APPENDIX 2 - Admin Center - User Interface Details	92
12.1	Main Screen	92
12.2	Sidebar	94
12.3	Dashboard	97
12.3.1	Camera Pane	97
12.3.2	Users Pane	98
12.3.3	Archivers and Storage Pane	98
12.3.4	Recorded Stream Quality Pane	99
12.3.5	Database Health Pane	99
12.3.6	License Information Pane	99
12.4	Navigation Tree Pane	100
12.4.1	View Dropdown - Navigation Tree Pane	100
12.4.2	Navigation Tree Tools	101
12.4.3	Selection Pane Tools –‘Add’ options depending on current view	101
12.4.4	Selection Pane Tools – ‘Filter’ options depending on current view	102
12.5	Configuration Pane	103
12.5.1	Configuration Pane Tools	104
13.	APPENDIX 3 - License Information	105
13.1	License Components	105
13.2	Licensing the Failover Directory	106
13.3	Failover Directory License File Installation	106
14.	APPENDIX 4 - Installation Overview	107
14.1	Installation Prerequisites	107
14.2	Installation Process	107

Table of Contents

15. APPENDIX 5 - Terminology 108

1 Introduction

1.1 Scope

This document is designed to enable Administrators to get up-and-running with the minimal basics of the system and is not intended to replace the user documentation or training. This document does not cover best practices nor makes any assertions as to the recommended practices or design of physical security.

Administrators should be familiar with physical security basics, practice due diligence, and observe applicable laws regarding their use of the system in the various jurisdictions within which they operate it and its features.

This document is limited in scope and does not attempt to teach security principles or hardware installation. It is provided to allow licensed and knowledgeable security users a quick-start overview of the systems basic features and configurations.

This document covers the AdminCenter for United VMS 9.2.7.

1.2 Finding What You Need

Introducing the System and getting started

1. [Introduction](#): Introducing this guide, this section provides background information – who is intended to use the Guide, tips on where to find more information, should you need it, and a short [overview of the system](#).
2. [Licensing your VMS](#): Preparing for a Latitude System and applying your Latitude license.

Configuring the System

3. [Using the Quick Configuration Wizard \(QCW\)](#): The Quick Configuration Wizard leads you through the initial setup of your Latitude System.
4. [Setting up Cameras in the Latitude System](#): This section takes you through the process of configuring cameras.
5. [Setting up other Entities](#): Adding Microphones and Speakers.
6. [Logical Configuration](#): Tailoring the system to match your structure.
7. [Setting up Specialized Servers](#): Transcoder, Gateway, Case Builder and Web Server.
8. [Alarm Management](#)
9. [User Management](#)

Appendices with detailed information

- Appendix 1 - [‘How to’ Configuration Information](#)
- Appendix 2 - [Latitude Admin Center - User Interface Details](#)
- Appendix 3 - [Latitude License](#)
- Appendix 4 - [Installation Overview](#)
- Appendix 5 - [Latitude Terminology](#)

1.3 Intended Audience

This Guide is written for the administrators of the **Latitude AdminCenter** who are responsible for setting up systems, adapting it to fit the needs of the site, and keeping it running. Admin Center users must be able to set up facilities for the **Latitude ControlCenter/s** operators, who are the primary users of the Latitude Video Management System.

In this Guide, we try to cover the basic setup of the system.

A separate publication, **Latitude ControlCenter Quick Reference Guide**, covers the operation of the ControlCenters.

1.4 More Information – Help System

Once you have completed the initial installation of the system and you have the AdminCenter running, you'll find that there is an extensive context-sensitive Help system available at all times, simply by clicking the  symbol in the top right-hand corner of the screen. The Help system defines all parameters in the system and also provides information on using the Latitude System's features.




Figure 1 - Accessing Latitude Online Help

1.5 About this File

Welcome to the United VMS 9.2.7 Latitude Admin Center User Guide.

Note: Changes to this file were last introduced after Application Build No: 3331

Summary of latest changes:

Change	Date Changed	Summary	Links
Release	March 2023	9.2.2	
Release	October 2022	9.2.1	
Release	April 2022	Updated version and build for release.	
Release	December 2024	9.2.7 GA Release	

File information:

Source file: Latitude_AdminCenter_9.2.7_UserGuide. pdf Date compiled: Monday, December 30, 2024

2 FLIR United VMS Latitude System Overview and Main Components

The FLIR United VMS Latitude system is a **network-based video and audio management system** comprised of servers, client workstations, connected edge devices (e.g. encoders, decoders, IP cameras, etc.) and additional optional components, such as external storage modules, sensors and keyboards.




Figure 2 - Schematic – a Latitude Network Video Management System

2.1 Servers

Directory Server

The Directory keeps all the configuration information about the system. This allows it to:

- Manage System Configuration Data
- Handle Alarm Management
- Handle Incident Management
- Manage failover in the event of a Server failure

EDB Server

The Event Distributor is used as an interface for passing events and actions between different Latitude components, as well as between the system and external devices and programs.

Archiver

The Archiver is a server that communicates with all the systems devices. It is responsible for:

- Pushing down settings such as resolution, frame rate etc.
- Recording
- Routing video to the various clients

Transcoder/s

The Transcoder is responsible for transcoding video content (Live and Playback). It can be set to downscale resolution and change video compression (for example to MJPEG), and by doing so it allows the system to transmit video over the internet.

Gateway Server

The Gateway Server acts as the interface to the system for remote or external connections.

CaseBuilder Server

The CaseBuilder allows operators who have the appropriate system privileges to collect and organize data into Cases, and copy and export those Cases in a verifiable form to a shared location outside the Latitude system, so they can be accessed by other systems. For example, a Case may be taken off-site for third-party investigations or to a court of law.

Web Server

The Web Server allows internet-connected users to view live and recorded material, using the Web Client provided with the system. Transport Layer Security may be used to encrypt all Web Client communications.

Application Server

The Application Server is a component that is responsible for hosting SDK services.

2.2 Latitude Clients - Admin Center, Control Center and Web Client

ADMIN CENTER CLIENT

The Latitude AdminCenter enables you to manage every aspect of the system, including camera settings, recording parameters, user access and privileges, alarm behavior, and more.



Figure 3 AdminCenter console showing a camera parameter screen

Once the system is running, the AdminCenter is used to monitor system health, add new devices when required, and to reConfigure the system when necessary.

The AdminCenter also allows operators to perform backup of system data.

CONTROL CENTER CLIENT

Latitude Control Centers are the consoles at which operators can monitor selected live cameras, search for recordings and watch them, monitor alarms that are raised by the system or that are input manually, and respond to them.



Figure 4 A ControlCenter console set up with multiple monitors

The Latitude Control Center is highly configurable, and each Control Center can be set up to suit the needs of specific operators. Where computers are equipped with multiple screens, then each ControlCenter can spread its display over multiple monitors (as shown above).

WEB CLIENT

The Latitude Web Client enables authorized users on connected PCs to watch live and recorded material, take snapshots, export clips and respond to alarms without needing to install any client software, just by using a supported Browser.




Figure 5 Web Client in a standard Browser

2.3 Security for Your FLIR United VMS Latitude System

Security is becoming an increasingly important topic for users of computer systems - especially for those with large IP networks. For large VMS systems, apart from normal security considerations common to all computer systems and networks, several additional vulnerable areas need to be considered.

- **Equipment from multiple vendors** - each with their own widely-known default passwords
- **Managing distributed configurations** - needing to send control information to and from cameras
- **Access via browsers** - requesting and receiving video streams

FLIR United VMS Latitude Provides security features to reduce the risks associated with these vulnerable areas.

The FLIR United VMS Latitude **System** entity setup includes two tabs that allow the user to set up security policies and administer them. A brief summary of the facilities available is provided below.



Deciding on security policies and implementing them requires in-depth knowledge of the alternatives, and users are urged to discuss these with their Teledyne FLIR support representatives when setting up their systems or making changes to the configurations.

The [System Security tab](#) and [Edge Security tab](#) are accessed from the **System/General** page in the Logical or Physical view.




Figure 6 Accessing the System Security and Edge Security Tabs

2.3.1 System - System Security

The System Security tab has the following panes: [Edge Security Settings](#), [Web Security](#), [Users Password Rules](#).




Figure 7 System Security Tab

Edge Security Settings

TLS for Edge Devices – Policy

Establishing and applying these facilities requires support in the system and from the edge devices themselves. Check the Admin Center Help file for details of what facilities are supported in your installed version.

TLS for Edge Devices – Choosing the options

The user sets under what conditions Edge Devices may communicate with the system.

Terms used here:

Secured Connection - Communication uses HTTPS and encryption to ensure integrity of messages and guard against malicious users.

Self-signed - Certificate is generated by the camera (or unit), rather than by a third-party Trusted Certificate Authority

	Parameter	Comments
☐	Use secured edge connection if available: - Connecting new units - Rediscovering existing units - Performing firmware updates	IMPORTANT: APPLIES UNITS IN THE CASES SHOWN - Other Units already in the system are not affected. 1. If this option is enabled the Archiver tries to establish a secured connection with the camera. If it succeeds then all the communication with the camera is encrypted. 2. Discover using FLIR Plug-in or ONVIF method. 3. Units must support HTTPS and have certificate already loaded, or have already created their own self-signed certificate.
☐	Block communications for devices using unsecured connection, but allow user to secure them	APPLIES TO ALL UNITS. Archiver blocks all communication from units except those actions that are required in order to set up secured connections. (More strict)
☐	Block communications for devices using untrusted certificates, but allow user to replace them	APPLIES TO ALL UNITS. Archiver blocks all communication from units except those actions that are required in order to replace the certificates. (Most strict)

Details of steps to complete the set up of TLS for Edge Devices are given in the Admin Center Help file.

Web Security

This panel allows the user to activate and deactivate TLS (Transport Layer Security) encryption between the Web Server/Transcoder and any Web Clients that are in use. Details of steps to complete the set up of TLS are given in the Admin Center Help file.

Users Password Rules

This panel allows you to create rules regarding passwords across the system.

Settings include the following:

- **Disable rules**
- **Allow password to be identical to user name**
- **Minimum length**
- **Minimum number of letters**
- **Minimum number of digits**
- **Prohibited Passwords**
- **Users may not change passwords**

2.3.2 System - Edge Security

This page enables users to view the current Security mode for all units and where applicable, enables the Administrator to change settings (on devices that support these capabilities).




Figure 8 Edge Security Tab



Note: Changing Edge Device Security Settings depends on the unit's inbuilt capabilities, and on the method that was used to discover the unit.

Security Mode and Certificate changes can only be made on units that are covered by the FLIR Core Products plug-in, or were discovered as ONVIF units having the necessary ONVIF profile to support these actions.

For all other listed devices, the **Set Security Mode**, and **Generate Self-Signed Certificate** options are disabled (greyed-out).

Similarly, the **Change Password** option is only enabled for units that support password changes.

The table displays the following:

- Icons indicate the security status of the device:

Icon	Description
	Unit connection is secured, but does not have trusted certificate

Icon	Description
	Unit is fully secured (Secured connection and trusted certificate)
	Unit has security warning (see list below)
	Unit is unsecured
	Unit is blocked
	Unit is inaccessible

- The device name
 - Whether the device connection to the archiver is secured or not
 - If secured, the expiration date of its certificate
 - Whether or not its password has been set by the user or is still set at the factory default
- Note:** Units discovered using the ONVIF plugin display **Unknown** as the plugin does not provide a method that can determine if a 'new' password has been used or if the user entered a value that corresponds to the manufacturer's default password.
- The status of the last action initiated for that device

When a device in the table is selected, any applicable security alerts for the selected device are displayed, and the available changes to security status are enabled.

Security Actions

The following Security Actions are shown above the table:

Set Security Mode Set TLS Certificate Change Password

- **Set Security Mode**
- **Set TLS Certificate**
- **Change Password**

Notes:


- Each of these **Security actions** can be applied to one or more entries in the table. The actions are only enabled if they are available for the device or devices **selected**. i.e. If more than one entry in the table is selected, only actions that are available for *all selected devices* will be enabled.
- When the user has Quasar Gen II and/or IOI-HD units, the following warning message displays:
 Warning. After Firmware upgrade, camera certificate must be reloaded.
- When using **Change Password** on PTZ Cameras:



The **Change Password** functionality interrupts an open PTZ session, and can affect PTZ functionality.

Admin Center operators who wish to change password on PTZ cameras should follow these steps:

1. Go to **Edge Security** page, and change the password.
2. Go to the **Camera/PTZ Configuration** page (shown here), and carefully note *which PTZ Driver is in use* for the camera (circled).
3. Disable **PTZ Configuration** (deselect), and save the change .
4. Re-enable **PTZ functionality** (select), using the driver that was in use (Choose from the drop-down menu), and save the change .



3 Licensing your VMS

Details of the license, including real-time usage details, can be viewed in the AdminCenter.

Follow these steps:

1. Go to the **AdminCenter**.
2. On the **Sidebar**, click **System Settings**.
3. In the System Settings **Navigation window**, select **License**.

If the FLIR United VMS Latitude Admin Center is opened on a system for which a license has not yet been installed, you must apply a license file. When your system was purchased, you were sent an email with an **activation key**, and a link to the **Customer Portal**. There, the user establishes a username and password, and can download the Activation Key associated with the purchased product. The Install License window opened by the Login process leads the user through the steps required in order to install the license.



The user should keep the invitation and the the credentials generated for the Customer Portal - this information may be needed again if a license upgrade is required.

Licensing for large systems is usually completed by the Integrator during installation. However when a user wishes to upgrade the system capabilities, for example by adding more video channels, or using an add-in capability, a new license may be required.

Full details of the Licensing process are given in the Licensing User Guide document which can be found on the Documentation Web page.

Note: For an overview of [Licensing a system](#), see below.




Figure 9 Licensing Tab



Your Activation Key is displayed in this view - keep it confidential!

License Information

This lists all possible licensed components and features.

Feature Information column For each entry, this shows the feature as Not Supported, Supported, Unlimited, or shows the maximum allowed number of licensed instances.

Usage column shows the current status for the component/feature ('Not in use', or the number of instances currently in use).

Feature	Comment
Active Directory integration	Enables the option to integrate with Microsoft Active Directory - Supported / Not supported
Add-on component	Number of permitted Add-On components -- Add-On component licenses will be provided by Teledyne FLIR with the purchase of engineering service integration modules

Feature	Comment
Case Builder	Enables the use of the Case Builder application - Supported / Not supported
DSF connection	The Direct Show Filter connection - Supported / Not supported
Failover Directory	The number of failover directory servers in the system, not including the primary directory
Failover video channel	Number of supported camera scenes or analog monitor scenes for which the Archiver failover mechanism is licensed
GIS Mapping	The GIS Mapping feature - Supported / Not supported
Global user	Number of global user connection licenses
Keyboard connection	Number of CCTV Keyboards concurrently configured in the system
Mobile User	Number of Mobile Users Licensed/Active
Mobile Video Feed	Number of Mobile Feeds Licensed/Active
Privacy Masking	Supported / Not supported
Recorder	Number of supported Recorders
Redundant Channel	Number of supported camera scenes or analog monitor scenes
Reporting Tool	Licensed to use Pre-defined Reports - Supported / Not supported
SceneTracker Channel	Number of SceneTracker user connection licenses
SDK connection	Number of logins to the Directory server from SDK applications
SNMP	Enables the administrator to send out SNMP traps to any 3rd party Network Management System and to configure which Latitude events will be sent out as traps - Supported / Not supported
User session	Number of concurrently active user sessions logged in to the Directory server
Video channel	Number of supported camera scenes or analog monitor scenes
Virtual video channel	Number of supported matrix outputs
Web Client user	Number of concurrently active Web Client sessions logged in to the Directory server

System Information

This section shows the Activation Key in use and its Expiration Date, and shows the current server components with their license status.

Selecting a server in the table enables the **Install License** button, which allows the user to add or change licenses, or install licenses on additional servers.




Figure 10 System Information Window

Licensing a System

The Licensing process is normally completed with your representative.

Below is a brief overview of the process.

Getting to the Install License Window

The first time you log on (to an unlicensed system), the system opens the System Settings/Licensing page, and opens the **Install License** window.

If the system is already licensed and you wish to change the license or add a device to the license list, then go to the **Systems Settings/License** screen, select the device which you wish to license, and click **Install License**.

This opens the **Install license** window.




Figure 11 Install License Window

Get an Activation Key

You need an **Activation Key** to install a license.

This may be

- Provided by your representative,

OR

- You (or your integrator) are invited to register on the Client Portal, to get your keys on the FLIR License Management Portal (<https://licensing.flir.com>)



The invitation is one-time. Keep a record of the username and password used when you register, so that you can access the site again in the future if needed.

1. Navigate to the FLIR License Management Portal and log in with your username and password.

A table opens displaying your Activation Key/s.

The screenshot shows the FLIR Licensing Client Portal interface. The browser address bar displays 'https://licensing.flir.com'. The page has a dark blue header with the FLIR logo and the tagline 'The World's Sixth Sense'. A sidebar on the left contains links for 'Licences', 'New Device', and 'Active Devices'. The main content area, titled 'Licenses', features a search bar and a table of license entries. The table has columns for Name, Version, Activation Key, Issue Date, Evaluation, Subscription, and Activatable. Three entries are visible, all for 'Latitude' version 8.0, with different activation keys and issue dates.

Name	Version	Activation Key	Issue Date	Evaluation	Subscription	Activatable
Latitude	8.0	2A4NW-K7Z7S-VLXDT-F8F98-X2PML	2 April 2017	×	×	✓
Latitude	8.0	28SV9-37HV7-RKMDD-ZWBYA-2M8SF	20 March 2017	×	×	×
Latitude	8.0	29YCY-VTSLR-M942L-SXJX3-8EEBR	2 April 2017	×	×	✓

Figure 1:

Figure 12 Licensing Client Portal


2. Select the **Activation Key** to be used and copy to Clipboard.

To Generate a License

1. Paste the **Activation Key** to the **Install License** window, and click **Generate Request**.

The screenshot shows the 'Install license' dialog box. It contains instructions to follow steps to install a new license file. Under 'Activation Steps', there is a text field for the 'Activation Key' with a placeholder '(Paste your Activation Key here)' and a yellow 'Generate Request' button. Below this is a 'License file name' field with a 'Browse..' button. At the bottom, there are 'Install License' and 'Cancel' buttons, and a link to the 'Licensing Web site'.


A 'request.txt' file is generated.



2. Save the Request file on your system.

Activating the License File using the Client Portal

1. Go back to the Customer Portal window, and click **New Device**.



2. Click **Browse** to navigate to request file that was saved, and click **Activate**.
A license is generated and the screen displays a **Download License** Button.
3. Save the file using the **Save File** dialog, and return to the **Install License** screen.
4. Browse to the saved License file, and click the **Install License** option.

Details for Licensing additional Servers or installing a new License are given in the AdminCenter Help file.

4 Using the Quick Configuration Wizard (QCW)

The Quick Configuration Wizard (QCW) guides you through setting up the basic system to enable video monitoring and recording. Wherever possible, defaults are preselected to suit the needs of a standard installation, so the new user has only to enter data for variables particular to their installation.

Notes on Security

Latitude now includes facilities to increase system security by setting policies relating to communications rules between the system, edge devices, and web client connections. Update edge device passwords so that their manufacturer default passwords are no longer effective.

The [Security for your FLIR United VMS Latitude System](#) section provides a description of the facilities available.



Deciding on security policies and implementing them requires in-depth knowledge of the alternatives. Depending on your configuration and your requirements, some steps may be required before discovering edge devices, and some can only be implemented after the configuration is set up. Users are urged to discuss these with their Teledyne FLIR support representatives when setting up their systems or making changes to the configurations.

4.1 QCW – Prerequisites

The QCW prerequisites are as follows:

- **Archiver Configuration:** The storage location of the Archiver/s must be correctly formatted before starting the Quick Configuration Wizard.
The storage location must be formatted by setting the block size of the storage drive to 64K, and disable indexing.
- **Setting Network Addresses for Edge Devices:** Before beginning the system configuration, make sure that all your encoders, decoders, and IP cameras are assigned addresses consistent with at least one of the networks on which your Archivers reside. Consult the technical documentation of the units for information on how to assign IP addresses to them.

Note: The automated Discovery processes does not discover edge devices (cameras, encoders, etc.) that are on networks different from those to which the Archiver/s are connected. Use the Manual Discovery steps for these edge devices.

4.2 Starting the QCW

The wizard opens after installing the license. If the wizard is not already open, it can be accessed from the Latitude Admin Center Dashboard screen by selecting **Wizards/Quick Configuration Wizard/System**.




Figure 2:

Figure 13 – Opening the Quick Configuration Wizard

The Welcome screen shows the following steps (in order) to follow as you progress through the Global Configuration Wizard:

- **Global Settings** – Set the system defaults
- **Archivers** – Define the Archiver/s and the Network/s to which they are attached
- **Discovery** – Locate Edge Devices on the specified Network/s
- **Attach Units** – Associate the Edge Devices with Archiver/s
- **Quality** – Set video encoding parameters
- **Finish** – You have completed the QCW

Click **Next** to open the Global Settings Screen.

4.3 QCW - Global Settings

Figure 14 - Quick Configuration Wizard - Global Settings Screen

The Global Settings fields are set to the most commonly-used defaults. You only need to change them if your site has some exceptional conditions.

Table - Quick Configuration Wizard - Global Settings - Defaults and available options

Field	Default	Other Possible Values
Default NTP Server - Check-box Address field	Unchecked Blank	Optional - if you want to use an NTP Server, check the box and enter the NTP Server's network address.
System default time zone	Current Windows settings	Choose from drop-down
Default video source type	NTSC	PAL
Default archiver live connection type	Unicast UDP	Multicast, Unicast TCP, Best available
Default archiver recording connection type	Unicast UDP	Multicast, Unicast TCP, Best available

Field	Default	Other Possible Values
Default client connection type	Unicast UDP	Multicast, WebSocket TCP, Best available
Video scene creation enabled (check-box)	Checked	
Audio scene creation enabled (check-box)	Unchecked	
I/O scene creation enabled (check-box)	Unchecked	

1. Update any defaults if required.
For example, if you want to use audio and I/O capabilities, the relevant options must be selected.
2. Click **Next** to open the **Archivers** Screen.

4.4 QCW – Archivers

A table showing Archivers defined in the system displays:




Figure 15 - Quick Configuration Wizard - Archiver List

1. The first time you use the Wizard, the list is blank - click **Add** to create a new Archiver.

The **Archiver/General** screen opens.




Figure 16 - Quick Configuration Wizard - Archiver Name, Network address

2. Enter the name of the Archiver in the **Name** field, and the host name or IP address of the computer on which the Archiver resides in the **Network Address** field.
This can be Hostname or the machine's IP address.

Note: The Archiver Server application must be installed on the target machine before adding it to the configuration. Refer to the Latitude Release Notes for more information.

3. Click **Next** to open the **Network** screen.

4.5 QCW – Adding a Network

- 1. The **Network** Screen of the **Create Archiver** wizard appears. If you are starting a new installation, the list is blank.




Figure 3:

Figure 17 - Admin Center - Network List

- Click **Add** to add the network/s to which the Edge Devices are connected.




Figure 18 - AdminCenter - Add Network Screen

- Enter the details of the Network you are adding.

Table – Quick Configuration Wizard – Add Network Details

Field	Value
Base IP Address	e.g. 192.168.2.0
Subnet mask	255.255.255.0
Default gateway	(Optional)

- Click **OK**.
You return to the previous network screen, and the details that were added now display, together with any other networks that may have been previously defined.
- To add another network, click **Add**.
(This returns you to Step 2 above.)
- When you have added and selected all the required networks, click **Next**.

4.6 QCW – Configuring Archiver Storage

The **Storage** dialog displays.




Figure 19 – Quick Configuration Wizard – Archiver Storage Definition – Waiting

The **Waiting** message indicates that the system is still looking for Storage information, and the list of available storage is blank.

As soon as the Storage is located, the message disappears, and a list of the available drives on the Archivers that were specified in Step 1 above is shown.




Figure 20 - Quick Configuration Wizard - Add Storage

1. Click **Add**, and the Storage table displays a drop-down in the **Drive** column where you can select which drive on the Archiver you wish to use as storage.





Figure 21 - Quick Configuration Wizard - Adding Storage Locations

2. Use the **Storage** drop-down to allocate storage space on the drive (typically 1000 GB).
3. Recommended **Container Size** is 80MB.

Notes: If the parameters you use are less than the minimum recommended Storage configuration, a warning message is displayed, giving you the opportunity to go back and change the parameters.

Other parameters may also not meet the recommendations of the system (e.g. Formatted block size of the target drive, attempt to Configure storage on the C drive, etc), and such conditions will be listed so that the Administrators can take appropriate action.



This process can repeat to define multiple storage locations.

- From the Quick Configuration Wizard Archivers screen, click **Next** to open the **Discovery** Screen.

4.7 QCW – Discovery

The **Quick Configuration Wizard Discovery** screen is shown.




Figure 22 - Quick Configuration Wizard - Discovery Screen

If the units you need to discover are on the same network as the Archiver then the **Automatic** discovery can be used.

Clicking **Start Automatic Discovery** on this first screen runs the discovery process for all defined **Archivers**, on all their attached **Networks**, using the stored **Discovery Settings**.



Running the Discovery feature may take several minutes.

One way to reduce time is to click on **Discovery Settings**, scroll through the list of proprietary cameras and units, and deselect any type/s you do not want included.

Automatic and Manual Discovery

For most uses, the Latitude **Automatic Discovery** process is the normal way to discover and attach cameras for an installation. The first page of the Discovery process looks at all cameras attached to the Archiver or Archivers that have been defined, and on all networks defined as being attached to those archivers.

The parameters for the automatic process are stored as a set of **Discovery Settings**. These settings allow you to discover any cameras on the network that fit the list of possible suppliers and models. Initially, these are the camera manufacturers' default settings. If necessary, users can click the **Discovery Settings** button and make changes to the stored settings, and the new values are then used for any subsequent automatic discovery processes.

This is covered in more detail in the sections on Discovery Settings below.

Alternatively, the **Manual Discovery** process discovers individual cameras, based on their Network Address, manufacturer and model information. (The Manufacturer and Model information allows the system to use the appropriate driver information needed to communicate with that particular camera (the 'plug-un'))

If required, these processes can be run multiple times, to build up a complete list of discovered cameras. Latitude then allows you to add the discovered cameras to their Archiver.

The process is described below.

Single boxes are operator actions. Boxes with double lines are actions carried out by Latitude.




Figure 23 - QCW - Automatic and Manual Camera Discovery

4.7.1 Automatic Discovery

Use this method when the units to be discovered are on the same physical networks as the Archiver.

The default **Discovery Settings** include a set of 'plug-ins' which cover all proprietary entities that Latitude has pre-defined. If required, these settings can be changed by clicking on **Discovery Settings**. The Discovery Settings screen appears.

Note: The **Discovery Settings** are only used by the Automatic Discovery process, and not by the Manual Discovery process.

Figure 4:

Figure 24 - Discovery Settings screen

Proprietary Discovery, Latitude initially sets the parameters for each manufacturer and product category corresponding to the manufacturer's default settings.

1. If you have changed the manufacturer's settings (such as Username and Password defaults) in some or all of the entities to be discovered, then change the settings in the relevant groups. Then click **OK** to return to the **Quick Configuration Wizard - Discovery Screen**.

There are additional facilities in support of the FLIR family of products which simplify the discovery process - see [Discovering FLIR cameras and encoders](#).



The Discovery process covers products that support multicast. Some devices, including FLIR Recorders, only support unicast, and therefore must be discovered manually.

2. Once you return to the Automatic Discovery screen, click **Start Automatic Discovery**. The system adds all the units it locates to the Discovery screen list. When you have seen all the units that need to be discovered, click **Stop automatic Discovery** to end the process.
3. The cameras that have been discovered are added to the list in the Discovery screen and process continues at [4.8 QCW - Attach Cameras to Archiver](#).
4. **ONVIF Discovery -**
If you want the discovery process to use only ONVIF information, select the **Enabled** option in the ONVIF section to disable all the proprietary parameters.

4.7.1.1 Discovering FLIR Cameras and Encoders

Scroll to FLIR section of the Discovery Settings screen.




Figure 25 – FLIR Camera Plugin Settings - Common Settings

The FLIR Plugin uses the stored discovery settings for all FLIR integrated products, without the user needing to set up the individual parameters for the different models. However, if needed, the user can access one of more particular model or model range, to make appropriate changes.




Figure 26 – FLIR Camera Plugin Settings - Model / Model Ranges

For each model or model range, the stored parameters display and can be updated if required. Common Settings cover the majority of cases, and if necessary, the user can select a particular model if some specific parameter in the stored settings needs to be changed.




Figure 27 – FLIR Camera Plugin Settings - Examples of specific model parameters

4.7.2 Manual Discovery


Use this method when the units need to be discovered manually – for example, when they are on a different network from the Archiver.

Follow these steps:

1. From the **Quick Configuration Wizard - Discovery Screen**, click **Run Manual Discovery**. The **Add Unit manually** dialog displays.

Figure 28 - QCW - Add Unit Manually screen

2. Do the following:
 - a. In the **IP address** field, enter the IP address of the unit to be discovered
 - b. Use the **Unit Type** drop-down arrow to select the manufacturer/model family
 - c. Click **OK**.
- A progress bar displays while the system searches for the unit.



The system indicates when the unit has been found.




Figure 5:

3. Click **OK** on the information dialog.

The Discovery Screen displays, with the camera added to the list. The process continues at [3.8 QCW - Attach Cameras to Archiver](#).

4.7.3 Adding Generic Cameras

The Generic camera plug-in enables users to configure edge devices that are not integrated into the FLIR VMS system and are not ONVIF Compliant. This plug-in supports any edge device which transmits a standard RTSP H.264 or MPEG4 stream, or alternatively MJPEG over HTTP.

Note: Using this plug-in, users are only able to **view live** and **record the stream**. Configuring video or picture settings from Latitude, using motion detection, PTZ and other features **are not supported**.

Configuration:

Discovering a camera via the Generic Camera Plug-in is done manually, in the '**Add unit manually**' screen. You can access the screen using one of the following methods:

Add the Unit to an Archiver manually




Figure 29 - Add Generic Unit Manually

OR

Discover a Unit manually from the Discovery page




Figure 30 - Discover Unit Manually from Discovery page

Follow these steps:

1. Open the **'Add Unit manually'** screen using one of the above methods.
2. In **Unit Type**, use the drop down arrow to select the **Generic Camera** option.
3. In **Video Compression**, use the drop down arrow to select the compression setting.
4. Check video port (and audio port if required) settings.
5. Enter the appropriate suffix information for the device as specified by the supplier, and click **Add**.
6. Repeat for each required stream, and click **OK**.

For each stream, the full **Unit/Port/URL suffix** are displayed in the table.

This is updated if the user changes the IP address Compression method or URL suffix.

4.8 QCW - Attach Cameras to Archiver

After the Discovery process, the Quick Configuration Wizard lists all the Edge Devices that have been discovered.

Click **Next** to attach the cameras to the Archiver/s.



If there is more than one Archiver in the system, and some discovered cameras have not been attached to the previous Archiver, you have the option of attaching remaining available cameras to the second/subsequent Archiver/s.




Figure 31 - Quick Configuration Wizard Discovery screen showing Discovered list

Follow these steps:

1. In the table, in the **Name** column, use the check boxes on the left to select which units to attach to the archiver.
If you have more than one Archiver, the wizard starts with the newest Archiver, and when you have finished and click **Next**, it repeats with the second Archiver, and so on.
2. When you have attached all the required cameras, click **Next** to open the **Quality** dialog.

4.9 QCW – Quality

The **Quality** screen lists all cameras that were ‘Attached’ in the **Attach Units** (previous) step.




Figure 32 - Quick Configuration Wizard - Quality Settings


Follow these steps:

1. In the Set Quality setting, use the drop-down arrow to set a ‘quality’ level for the cameras that were attached.

Note: In the example shown, the setting ‘Medium (default) quality’ was used – all cameras in the list are set to their default settings that correspond to the selected value.

You can choose to change settings later through the **Camera** screen. You can also use the **Copy Configuration Wizard** to copy the configuration to other cameras.

2. Click **Next** to complete the process.
The Quick Configuration **Finish** dialog displays.



3. Click on **Finish** to close the wizard.



If you selected a quality setting and applied it to the phones that you attached to the archiver/s, then recording starts when you click on **Finish**.
You can choose to change settings later through the Camera screen.
You can also use the **Copy Configuration Wizard** to copy a configuration to multiple other cameras.

***Your initial set of cameras are connected to the Latitude System, and recording now starts.
You can now use the system!***

4.10 **Accessing Applications from the Sidebar**



This button enables you to launch various Applications.

Application	Notes
ControlCenter	The client application used by the operators who monitor the live video material, handling the alarms raised by the system, finding and viewing video clips of previous incidents, and preparing material for export from the system.

Application	Notes
	Note: Launching the Control Center from the Sidebar will use the same credentials that were used to launch the Admin Center.
Discovery Network Assistant (DNA)	Full set of Edge Device tools for setup and configuration of FLIR Edge Device IP addresses, Security/Credential settings, Video mode and Firmware updates.
Reporting Tool	An application that provides reports on Latitude events by querying the audit databases maintained by the Latitude EDB servers (e.g. reports on User Logon , Entity Configuration, Incident, Alarm, Equipment Failure, and Server Monitoring).
MapBuilder	An application that allows the creation of full-featured security maps. Camera Icons can be placed on schematic maps or on aerial photographs.
TruWITNESS Assignment Tool	For users of TruWITNESS Situational Awareness facilities, this tool runs the application that assigns/reassigns TruWITNESS appliances to users.

4.11 Accessing Wizards from the Sidebar



This button provides access to the Latitude Wizards.

Application	Notes
Quick Configuration	Takes the user through the steps of setting up the Latitude system for the first time - defining global settings, location and configuring key servers, as well as discovering, adding and configuring units. Described in detail in Using the Quick Configuration Wizard (QCW) .
Camera Wizard	A wizard that takes the user through the steps of adding and configuring units and configuring the camera settings, recordings and events.
Copy Configuration	A dialog for selecting and copying key configuration between similar units and entities. Described in Using 'Copy Configuration .
User Group Wizard	A wizard that takes administrative user through the steps of creating custom User Groups, assigning privileges and rights to the group, and selecting users to belong to the group.

5 Setting up Cameras in the Latitude System

During the initial setup phase, once cameras are attached and the system has applied their default parameters, you may wish to make specific changes to some of the settings. You'll normally only enter information that is unique to a particular camera (such as its name and description), and possibly adjust the picture settings to suit the camera's position and surroundings.

This section describes the Camera settings screens, and covers the areas where you may typically want to make changes.



The Admin Center enables the user to make detailed changes to all parameters controlling each camera. In this guide, only the more-often accessed parameters are covered. For detailed information about all settings see the FLIR United VMS Latitude Help file.

You can set up one device and use the **Copy Configuration** option to copy all or some of its settings to other devices.

Click the Help symbol  from any screen. The Help system provides detailed information on the contents of all fields.

5.1 Individual Camera Settings – the Camera Parameter Screens

The Camera screen enables you to select a particular camera (from the Logical, Physical or Video views), display all its parameters, and change them where necessary.




Figure 33 - Admin Center - Camera Parameter Screen

The screen is organized multiple tabs, each with panels that can be opened or closed.

At any time, only one tab can be open. Within the open tab, you can open (maximize) or close ('minimize') any of the panels.

The following tabs are described in this section:

- [General Tab](#)
- [Video Settings Tab](#)
- [Picture Settings Tab](#)
- [Edge Recording Tab](#)
- [Recording Settings Tab](#)
- [Linked Tab](#)
- [PTZ Configuration Tab](#)
- [PTZ Controls](#)
- [Motion Detection Tab](#)
- [Quick View Tab](#)

- [Privacy Masking Tab](#)
- [Actions Tab](#)

5.1.1 General Tab

In the **General tab** the user can name the camera, set up its connection type and its retention settings.


Note on Coverages and Profiles

The Camera settings described in the next sections ([Video Settings Tab](#), [Picture Settings Tab](#) and [Recording Settings Tab](#)) are all defined in terms of coverages (time periods) during which Profiles (sets of rules) are enforced.

In each of these tabs, default parameters are set and access to them is disabled (grayed out) unless you set a **Coverage**.

To set a new coverage:

- From the **Coverage** field, click on one of the available options:
 - **Add** - Add a new coverage
 - **Create New** - Create a new coverage.



5.1.2 Video Settings Tab

The **Video Settings tab** enables the user to set up the camera video parameters.


The user must choose resolution, FPS, and compression quality.

The separate **Live** and **Recording** settings enable you to use different settings – for example, high resolution when viewing live for maximum clarity, and lower resolution for recording to save storage space. If the camera is set up in separate streams mode, the same settings must be set for the recorded stream.

The **Advanced Panel** provides an option to carry out additional settings.

To access Advanced Panel settings:

- Set a Coverage in the **General** panel, and then select the **Advanced** settings options.
For more detail, see the online Help system.



5.1.3 Picture Settings Tab

The **Picture Settings** tab sets up picture parameters such as brightness, contrast etc. For more advanced settings, select the advanced option, and refer to the online help for information.

Note: These camera parameters are set up per camera, rather than using the system defaults.

Camera 1 - 192.168.50.106 (FLIR CC-3103-01-I F206T01529) - 44

General

Coverage: Always

Profile: Custom

Saturation: 0 to 100 (50)

Hue: -180 to 179 (0)

Contrast: 0 to 100 (50)

Brightness: 0 to 100 (50)

Advanced

Advanced settings: ☒

Sharpness: 0 to 100 (50)

White balance: Automatic

Noise reduction: [Dropdown]

Exposure mode: Automatic

Gain: 0 to 100 (50)

Exposure area: [Dropdown]

Input filter: [Dropdown]

Day/Night mode: Automatic

Mode switch sensitivity: [Dropdown]

Wide dynamic range sensitivity: Off

Color enabled: ☒

Back light compensation: ☐

Summary


Active	Coverage	Profile
✓	Always	Custom

5.1.4 Recording Settings Tab

This tab is used for schedule-based recording. It enables you to set when the camera records, and for how long the recording is maintained.

To set recording parameters:

- Add a coverage, and set the number of days you want to keep the video.



5.1.5 Edge Recording Tab

This tab is used for edge recording parameters and includes the following:

- **SD Card Information**


The following SD card Information options display:

- **Status** - Indicates the SD card status. A green check mark indicates "Ready".
- **Total space** - Indicates the SD card total space.
- **Used space** - Indicates the SD card space used.

- **Configuration**


The following Edge Recording configuration parameters display:

- **Profile** - Use the drop-down arrow to select from the available configuration profiles.
- **Edge storage cleanup policy** - Use the drop-down arrow to select from the available storage cleanup policies, including the following:
 - **Stop recording** - Stops the edge device from recording.
 - **Overwrite oldest recording** - Overwrites the current oldest recording.



5.1.6 **Linked Tab**

The **Linked** tab enables you to associate devices (i.e. microphones and speakers) with the current camera.
(See [5.1 Setting up other Entities: Microphones and Speakers](#)).



5.1.7 PTZ Configuration Tab

The **PTZ Configuration** tab provides you access to the camera Pan-Tilt-Zoom settings, driver configuration settings, and patterns and preset settings.




Figure 34 - Using the PTZ Tab



Latitude discovers the integrated IP PTZ camera default settings.

For other PTZ cameras, you must set up these parameters – consult the camera's documentation and the Latitude Help system.

- The PTZ compass window enables you position the camera to determine and set the home orientation, (and for each Preset or Pattern if required).

Presets


To set up a **Preset**, select a preset number, use the compass to move to a desired location, click **Edit** and enter a name, and click **Set**.

When you have defined the presets you need, click the **Save** icon .

Patterns

To set up a **Pattern**, select a pattern number, use the compass to set a desired location, click **Edit** and enter a name, and click **Set**.

When you have defined the pattern, click the **Save** icon .



5.1.7.1 PTZ Controls

The PTZ Controls enables you to access specific camera functions.




Table - PTZ Control Functions

Pan/Tilt controls:



Click on an arrow to move the camera in the indicated direction. Sensitivity is greater as you move further from the center

- clicking near the inside of the circle moves the camera in smaller steps.
- clicking near the outside moves the camera in larger steps.

Zoom In/Out:




Click to single-step the required change. Click-and-hold for continuous change.

**Toolbar:**

Note: All toolbar facilities are limited to cameras that have these facilities integrated into the <%ADMINCENTERNAME%> system.

Click on the required symbol:



- **Menu** - Allows direct interaction with the camera's built-in menu. The menu is superimposed on the camera view in the Preview window. (See Built-in Menus)



- **Home** - Click Home to return the camera to its Home position.



- **Flip** - Flips the image 180 degrees



- **Lock** - Disables the PTZ capability for other operators. (where supported) (This is a Toggle - clicking again re-enables)



Selection Number - Allows choice of a **Preset** or a **Pattern** (depending which mode is selected (by clicking on the **Preset** icon  or the **Pattern** icon ). The selected mode is colored orange, and displays to the left of the icons.

Note: When you hover over a **Selection Number** PTZ preset, a preset location snapshot displays for several seconds, providing a hint of the preset view.



The current selected mode is shown (**Preset** or **Pattern**). Click on the required mode or on the **AUX** or **SceneTracker** icons.



Preset – Click on a selection number moves the camera to show the preset view associated with that button.



Pattern – Allows the operator to record a series of camera moves, which are stored as a 'Pattern'. This recorded path is followed whenever the Pattern is invoked.



Aux – For devices that work on the same principle as a PTZ camera (e.g. mounted with a PT motor or servo). Allows one preset defined for each numbered load button.



Scene Tracker - When selected, works like a digital version of a pan, tilt and zoom preset within Scene Tracker views, remembering what viewed area of the composite Scene Tracker view was loaded when the preset was defined. Allows one preset defined for each numbered load button



The Edit controls allow **Presets** or **Patterns** to be set up, named and edited.

This area allows each preset to be named (Edit), and stored (Set). The pan tilt and zoom settings of the camera's current view is stored.

Allows one preset defined for each numbered load button up to 12. (Up to 256 Presets can be defined. Presets after the first 16 are available accessible through the drop-down in the Edit field.



Allows direct adjustment of the camera's aperture and focus settings

5.1.8 Motion Detection Tab

Motion Detection refers to the system's ability to 'notice' movement, and provides the following benefits:

- Records when movement is detected: This allows you to save recording space, as recording occurs when motion is detected.
- Trigger events when motion is detected: Events such as activating alarms, changing camera resolution to display more detail occur when motion is detected.

Motion detection is normally set up using the capabilities of the cameras themselves (edge-device based).

The parameters for setting up basic edge-based motion detection are described below.

Note: The Latitude system also supports archiver-based motion detection – for more information on this and for more details about edge-based motion detection capabilities, see the Help system.

The following describes how to set up motion detection for a camera.

Follow these steps:

1. Open the **Camera/Motion Detection** tab.





Figure 35 - Camera Screen - Motion Detection Tab

2. Before configuring Motion Detection, check the capabilities of the camera in the **Capabilities Panel**.



Capabilities	Settings
Client configurable unit based motion detection	Yes
Irregular shape zones in the unit	No
Motion indication	Yes
Multiple detection zones in the unit	6
Smart search support	Yes
Software motion detection full screen	No
Software motion detection with zones	No
Test motion detection in software	Yes
Unit based motion detection full screen	Yes
Unit based motion detection with zones	Yes

Figure 36 – Camera - Motion Detection Capabilities

3. Once you have verified that the camera supports Motion Detection, go to the **Motion Detection** tab / **Configuration Panel**.
All parameters are disabled until you set a Coverage during which Motion Detection is to be activated
4. Choose an existing Coverage or define a new one. Use the same procedure as for defining coverages for camera settings.
The Zones drop-down indicates what MD modes are available with this camera. If you want to use Edge Zones, then select an existing zone, or use the following steps to define a new one.
5. Click  and enter a name for the zone. This enables the Preview/Zone definition display.




Figure 37 - Camera - Motion Detection - Preview/Zone Definition

6. Select the **Edit zone** option from the drop-down to define a new MD zone.
A set of icons, as detailed below, enables you to use the cursor to define the zone.

Icon	Function
	Mark rectangle lets you define a zone by clicking and dragging a rectangle using the cursor.
	Mark All icon selects the whole field.
	Clear All icon clears the whole field.
	Mark Individual and Erase Individual allow you to define irregular zones (only when supported by the camera – usually these icons are disabled)

7. When you have marked the zone, you can select the **Test Zone** option in the drop-down to see whether the zone is set up satisfactorily.
As motion is sensed, it is indicated by the vertical bar on the right of the preview window. If motion exceeds the Motion On threshold, a red frame displays around the preview window. To reset and test again, select the **Idle** option in the drop-down, and then select **Test Zone** again.

Motion Detection parameters

Note: Setting these parameters is a complex task – you may want to make a note of the default parameters before changing them

Parameter	Description
Sensitivity	Overall sensitivity
Motion On Threshold	Proportion of motion to be regarded as 'Motion On'
Motion Off Threshold	Proportion of motion to be regarded as 'Motion Off'
Consecutive Frame Hit	Parameter that can be used to suppress low-duration events (such as random noise)

Note: Depending on the particular camera model, some of these parameters may not be supported.

Record upon Motion parameters

The table below gives basic details about these parameters. Three typical combinations of settings are indicated. These are explained below.

Normal – Use these choices to record only when motion is detected, with some automatic pre-event recording.

Advanced – As above, but when motion is sensed, switch to a higher resolution for the motion events, and then revert to normal resolution for live viewing


‘Boost on record’ – Record at low resolution, and use higher resolution for segments with motion.

Parameter	Description	1	2	3
Bookmark motion on events	i.e. bookmark on the regular video of this camera	☒	☒	☒
Record upon motion on	Always record when motion is sensed	☒	☒	☒
Pre-event recording	Select to include a recording of the selected time before motion started. Note: The system automatically buffers this camera so that this can be done. Only enabled when Record upon motion is set.	☒	☒	☒
Set recording video profile upon motion on	Allows selection of a different video profile when recording (normally higher than the profile used for live viewing)	i	☒	☒
Stop recording/restore profile	Set the time after which the profile used for recording can revert to the profile for regular viewing			

For more information, consult the Help file.

5.1.9 Quick View Tab

With **Quick View**, operators can navigate between cameras to choose and switch to a view to track a moving object in screens. In the AdminCenter, you can create **Quick View** zones for display on a camera scene as overlays, with each overlay linking to a relevant camera. When you view a scene in ControlCenter and **Quick View** is enabled, the operator can view the defined **Quick View** zones, on top of the video, and can navigate between the cameras using them.



For more information, consult the Help file.

5.1.10 Privacy Masking Tab

The **Privacy Masking** tab enables you to set up mask areas that are not visible to Operators. (User Privileges may be set to allow some operators to deactivate Privacy Masking)

For more information, consult the Help file.

5.1.11 Actions Tab

The **Actions** tab is used to select events related to this camera, and associate Actions with the Events.

The process of working with Actions and Events is described in more detail in the following sections:

- [Set Up Alarm Types](#)
- [Set Up How Alarm is Triggered](#)

System-Wide Events

Some events require similar actions, regardless of the entity from which they come. This means that you do not have to define the same event multiple times (for each entity that could cause it). The event is defined once, and the specified action will be carried out regardless of the origin.


These are described in [10.12 System-Wide Events](#)

5.2 Setting up Groups of Cameras

5.2.1 Using ‘Copy Configuration’

Copy Configuration gives a quick way to copy all or part of the configuration parameters from one entity to others that you select.

The Copy Configuration tool can be opened by right-clicking on a camera (or other entity) in the Physical, Logical or Video views.



Copy Configuration can also be accessed as a Wizard by clicking on the Sidebar/Wizards button.




Figure 38 - Copy Configuration Tool Screen - Camera



IMPORTANT NOTE: You can only use **Copy Configuration** for entities that already defined in the system.

The following procedure describes how to use the **Copy Configuration** option.


Follow these steps:

1. Depending on what entity is selected in the Navigation tree, the appropriate **Copy Configuration** window opens.
The **Select type** and **Select source** fields are pre-set for the entity selected when the screen was called, and all possible targets – that is, all entities that are of the selected Type – display in the **Select destinations** list.
The **Select categories** check boxes enable you to select which group or groups of parameters to copy to the target entity/s. The categories generally conform to the configuration tabs in the corresponding entity setup window, but exclude those settings which should always be individual.
2. The **Select destinations** list displays all entities that are of the same type as the one in the Source list, and whose characteristics in the selected 'Categories' can correspond.
For example, only destination cameras that support the resolution of the source camera are shown.
3. When you select the root entry option, all elements in the Destination list are selected.
Otherwise, select the individual elements you wish to reconfigure, and then click **Copy** to update all the selected entities.

6 Setting up Other Entities

6.1 Microphones and Speakers

Latitude enables you to attach analog microphones and speakers using the dedicated connection points on edge devices (cameras and encoders).



6.1.1 Define a Microphone or Speaker

A linked Microphone allows sound to be played/recorded together with the video image from the camera to which it is linked.

Follow these steps:

1. If a microphone or speaker was not created upon Discovery, you can go to the **Physical View**, and select the Edge Device to which it is to be attached.




Figure 39 - Add Microphone to Audio In Port

2. Select **Add Microphone** or **Add Speaker**.
The appropriate screen displays.




Figure 40 - Microphone Screen

3. In the **General** tab, change default name and modify other settings as needed.
On microphones for intercom use, set the **Audio Mode** in the **Configuration** panel to **Push to Talk**.
4. In the **Recordings Duration and Lifespan** panel, set Manual Recording parameters for microphones.

6.1.2 Link a microphone and/or speaker to a camera

A linked Speaker allows the operator to direct sound (usually from a microphone at the Control Center operator's console) to be played from the speaker associated with the camera.

Follow these steps:

1. In the **Logical View**, select the Camera with which the microphone and /or speaker is to be associated, and open the **Linked** tab.




Figure 41 - Camera - Linked Tab

2. Select a microphone and/or speaker from the list, and use the  add/remove (single) or  (multiple) buttons to add them to the list of items linked to the current camera. The Audio Link behavior is set to auto-record and auto-playback Audio with its associated Video.

3. Click **Save**  to save the settings associating this Microphone with the current camera



NOTE: For best results, it is recommended that the camera and microphone be from the same vendor.

7 Logical Configuration

Site/s can be organized according to both their physical structure, (how everything is connected), and according to the logical structure of the organization/s that use it to take into account individual needs.

7.1 Enterprises and Sites

Latitude allows you to arrange the Logical view of the system into Enterprises and Sites. By defining these structures, you can show logical entities (cameras, microphones, etc.), 'belonging' to different organizations or locations.

The example below shows how you can start with the entities that comprise the system, add a site ('Main Office', Office Area', Testing Lab', etc.) and drag the entities that are part of that site to its navigation tree, and then add another site ('Parking Area'), and populate the navigation tree for each site by dragging entities from the System root.

Access privileges in the User definitions can be used to grant or restrict operator access to sites. Where several organizations share a system (as in an Office building), the system can be further divided into 'Enterprises'.

Follow these steps:

1. Select **Logical View** from the Sidebar, right-click the **System** icon, and then select the **Add Site** option.




Figure 42 - Admin Center Configuration - Add Site

A new site is added with a default name ('New Site n'), and the Site screen is shown. You can give the site a suitable name and description.




Figure 43 - Name the Site

2. Add other Sites if necessary

Note: You can create sites within sites (and sites within enterprises) by right-clicking the applicable sites (or enterprises) instead of on the System root.

3. Now 'drag and drop' entities in the Navigation Tree to the relevant Sites.




Figure 44 - Drag-and-Drop entities to sites

Note: It is advisable to leave some entities, such as System Administrator, in the System root.

7.2 Sequences

A Camera Sequence is a succession of scenes that can be viewed in a tile.

This section describes how to create a camera sequence in the Admin Center.

Follow these steps:

1. In the Control Center, right-click the System icon and select the **Add Camera sequence** option.
OR
Right-click the Archiver in which you would like to place the sequence.




Figure 45 - Camera Sequence

2. Name the sequence and optionally, add a description.
If there is more than one Archiver, in the Information panel, choose which Archiver controls this sequence.
3. In the **Selected Cameras** panel, use the add/remove buttons (▶ ◀) to choose the cameras from the camera list, and add them to the right-hand list.
For each camera, enter the duration (Dwell Time) that it should be displayed.
4. (Optional)
 - To use a Preset view from this camera, use the drop-down to select the Preset.
 - You can change the order of cameras in the Sequence by selecting a camera in the table and moving it using the up and down buttons (⬆ ⬇).
5. Click  to save the Sequence.

8 Setting up Specialized Servers

The following are included in this section:

- [Web Server](#)
- [Transcoder Server](#)
- [Gateway Server](#)
- [Case Builder Server](#)

8.1 Web Server

A Web Server is needed if Latitude Web Clients are used.

Note: Normally, the Latitude installation includes the IIS configuration required for running the Web Server. For manual configuration, consult the relevant section in the Release Notes.

Add a Web Server

The following describes how to add a web server and various parameter descriptions.

Do the following:

- In the Admin Center, in the **Physical View**, right-click on the **System** icon and select the **Add Web server** option.
A new Web server displays with defaults as shown.

Table – Web Server Screen - General Tab

Field	Default	Notes
Information Panel		
Connection Status		 Connected,  Disconnected
Configuration Panel		
Name	New Web server	
Description		
Network Address		Enter address of the machine running the WebServer
Reported Address		
Web site is located in virtual directory option	Selected	
Virtual directory	Web Client	
Port	80	
Secured Website Port	443	See TLS - Setting up Encryption to/from Web Clients

Field	Default	Notes
External Address		

8.2 Transcoder Server

The Transcoder is a server application that trans-codes the MPEG4 video generated by encoders/IP cameras (and archived by Latitude) to standards-compliant MJPG-over-HTTP and standard video streams over RTSP/TCP, for transmission over the Internet.

At least one Transcoder Server is needed in a Latitude system to support connections of Web Clients. It is also needed if the installation is to support remote connection of Clients.

Add a Transcoder

The following describes how to add a transcoder and various parameter descriptions.

Do the following:

- In the Admin Center, right-click on the **System** icon in the **Physical View** and select the **Add Transcoder** option.
A new Transcoder is defined, with defaults as shown.

Table - Transcoder Screen - General Tab

Field	Default	Notes
Information Panel		
Connection Status		 Connected,  Disconnected
Server configuration Panel		
Name	Transcoder server	
Description		
Network Address		
External IP		
External Port	8080	External and Internal Ports must be the same
Internal Port	8080	External and Internal Ports must be the same
Secured Port	8081	Used for TLS communications to Web Clients
RTSP Port	5554	
Default transcoder	deselected	
Transcoded stream configuration Panel		
Compression quality	8	Range 1 – 10

Field	Default	Notes
Maximum frame rate	30	Range 1 – 30
Maximum resolution	240p	
Compression	H264	
Global performance limits Panel		
Total CPU % limit	50%	Range 0 – 100
Above limit enable 'Key-Frame only' mode	unchecked	
Max. concurrent transcoded frames per second	100	Range 50 – 500
Max concurrent client streams	20	Range 1 – 100

In the **Server configuration** panel of the **General tab**, you can edit the transcoder name and provide a description. Enter the network address of the new transcoder, and verify that the port settings are correct for your installation (See the Release Notes for more detail).

Note: If system loading is above the threshold set for the **Total CPU % limit** setting, transcoder requests are ignored to protect server performance.

8.3 Gateway Server

A Gateway server is needed if remote client applications are to be supported.

Add a Gateway Server

The following describes how to add a Gateway server and various parameter descriptions.

Do the following:

- To add a Gateway server, right-click on the System icon in the Server view and select the **Add Gateway server** option.

A new Gateway server is defined, with defaults as shown.

Table - Gateway Screen - General Tab

Field	Default	Notes
Information Panel		
Connection Status		 Connected,  Disconnected
Uptime		
State		
Version		

Field	Default	Notes
Configuration Panel		
Name	New Gateway server	
Description		
Network Address		Enter address of the machine running the Gateway Server
Reported addresses		
Routing		
Enable Gateway routing		
Port		

If external connections are used for connecting mobile devices, you must provide the IP of the server and configure a port in consultation with the installation's IP department.

8.4 Case Builder Server

A **Case Builder** server is needed for Control Center operators to open cases, add clips and other files, and export the cases.

Add a Case Builder Server

The following describes how to add a Case Builder server.

Follow these steps:

1. Create a network-shared folder for the CaseBuilder files storage location.
2. In the Admin Center, right-click on the **System** icon in the **Physical View** and select the **Add CaseBuilder server** option.
A new CaseBuilder server is defined.
3. In the **General** tab/Configuration panel, in the **Network Address** field, enter the address of the machine running the CaseBuilder Server.
4. Open the **Case Builder** tab, and in the **Data Location** panel, enter the network-shared folder path you created in **Step 1** and click **Test** to verify that the folder is accessible.

9 Alarm Management

An alarm is a special type of event that prompts users for a response rather than just providing a notification.

Alarm definitions are set up and initiated as follows:




Figure 46 - Set Up and Initiate Alarms

9.1 Set up Alarm Types

This section describes how to set up alarm types in the Admin Center.

Follow these steps:

1. From the **System Settings** view, use the drop-down arrow and select the **Add Alarm type** option.
The new alarm type configuration displays in the **General** tab.





Figure 47 - Define an Alarm Type

General Tab

Name the Alarm type (and if required) adjust the default values.

Cameras Tab



Where more than one camera is associated with an alarm, you can specify the Dwell Time (the amount of time each camera or clip is displayed before the next scene is shown) in the General tab of the alarm type's configuration pane. This tab is also used to Configure parameters such as Priority (which determines which alarms are shown if there are more active alarms than armed tiles in ControlCenter), Pre-alarm Coverage, and others.

2. Configure the remaining Alarm Type tabs, including:

Select Recipients – Users who receive alarm notification and can process it.




Figure 48 - Add Alarm Recipients

3. (Optionally) Add Cameras to be activated by the alarm (content from these cameras is displayed on the Control center when the alarm is triggered).




Figure 49 - Select cameras to be displayed for this Alarm Type

4. For each selected camera, you can click on the camera entry to display check boxes that enable you to configure when and for how long the camera content is used.
- View Live** – Select/deselect the **View Live** option to display/not display the Live Content
 - Record** – Select/deselect the **Record** option to enable recording of the selected camera related to the Alarm.
The current record parameters display as a link. Initially, the parameter displays **Not set**. Clicking on the link opens a "pre-alarm/post-alarm" edit window where the recording parameters can be changed.




Figure 50 - Alarm Type - Camera Record Settings


- Playback** – Specify playback time before and after the alarm. The same "pre-alarm/post-alarm" edit window opens allowing parameters to be set for Playback.

9.2 Set up How to Trigger an Alarm

This procedure describes how to trigger an alarm.

Follow these steps:

1. From the **Actions** tab of an entity, select the **Events/Actions** to trigger the alarm.
2. Right-click on the **Events/Actions** and select the action to be carried out from the available list.
The selected action displays under the **Events/Action** in the tree.
3. Right-click on the action and select the **Trigger Alarm** option.
The **Coverage** pane displays where you set action details.



4. Complete the Action parameters, including:
 - a. Select the **Coverage** during when the process is active.
 - b. Select the **Alarm types** triggered from the list of **Alarm types**.
5. Click  to save the alarm trigger.

For more information on Alarms, see the Help file.

10 User Management

Latitude features a robust privileges model that enables administrators to control user access to virtually every functionality and for every entity in the system. You can set these rules for each individual user in the system, and for each separate entity.

However, to make the rules easier to use, the system also allows rules to be copied ('inherited'). For example, you can set rules for a 'User Group', and then all members added to the group 'inherit' those rules.




Figure 51 -User Groups, Users, Privileges and Access Rights

It is convenient to think of the system as requiring several user levels – One or more Administrators, a number of Supervisors, and several groups of Operators. The entities making up the system can also be thought of as being grouped – the equipment/resources for different locations (Sites) – and sometimes different organizations (Enterprises).

Typically, one would define the User Groups so that all members of each group have similar rules. That way, when you define a new user, they can be placed into the correct group where their rules can be inherited from the group. For example:

Administrators can use all functions and view all entities.

Supervisors can view all entities in the Enterprises and on the sites they are responsible for, and carry out all Operator functions.

Operators can only view live and recorded content, and accept and close alarms related to the areas for which they are assigned.

10.1 Define User Groups and Users

This procedure describes how to define user groups and users.

Add a User Group

Follow these steps:

1. In the AdminCenter, click **User and Groups** in the sidebar area, and in the Navigation Tree tools, click the **Add** toolbar icon



, and on the context menu, select the **Add User Group** option.

The **User Group/General** tab opens.

The system assigns a default name 'New User Group n'.




Figure 52 - Defining a new User Group - General

2. Type the name you want for the group, optionally add a description, and click **Save** (💾).
The new user group name is added to the list of 'available users'.
3. Click **Create New User** to add new users quickly.

Figure 53 - Quick Create User

4. In the **Create New Users** dialog, enter the user name, username, password details and (optional) email address, and click **OK**.
The new user is added to the list of 'available users'.
5. Use the single arrows to move single users into (➡) or out (⬅) of the 'Selected users' list.
The double arrows ⇄ move the whole list at once.
You can then go on to set up the Access Rights and Privileges for the User Group or the individual User.

10.1.1 Access Rights

The **Access Rights Tab** is shown for User Groups and for individual Users. This tab enables you to determine what entities the user or user group can see.

Entity	Allow	Deny	Undefined	Inherited From
Central System (1)	☐	☐	☐	
Main Office	☒	☐	☐	Team 2
Office Area	☒	☐	☐	Team 2
Entr Cam0 (8)	☐	☐	☒	
Entr Cam1a (1)	☒	☐	☐	Team 2
Entr Cam1b (2)	☒	☐	☐	Team 2
Entr Cam2 (9)	☐	☐	☒	
OfficeEDDev Cam3 (3)	☒	☐	☐	Team 2
Office Entr and ED Dev Camer...	☒	☐	☐	Team 2
Office Layout (2)	☒	☐	☐	Team 2
Microphone 1 - 172.20.17.107 ...	☐	☐	☒	
Microphone Built-in - 172.20.1...	☐	☐	☒	
Reception Microphone 1 (1)	☐	☐	☒	
Parking Area	☐	☐	☒	
Testing Lab	☐	☒	☐	
New Camera sequence 2 (2)	☐	☐	☒	
OfficeEDDev Cam4 (5)	☐	☐	☒	
New Camera sequence 3 (3)	☐	☐	☒	
Outdoor GIS Location Map (1)	☒	☐	☐	Team 2

Figure 54 - Access Rights Tab

To set the Access Rights for this User Group (or this User):

- Check the radio buttons to set those entities (or groups of entities) to Allow or Deny.
 - **Allow** means that the corresponding entity or group is visible to this user or group of users.
 - **Deny** means that the user or group of users do not see this entity or group of entities, and cannot do anything related to it.
 - If you click on the radio button for a group entity (e.g. 'Main Site') then all the entities in that group are set to that value together.

Note: For a full description of all the fields in this tab, see the Help file.

10.1.2 Privileges

The **Privileges** tab enables you to define User or User Group functions.

Entity	Allow	Deny	Undefined	Inherited From
Monitoring applications (Control Cen...	☐	☐	☐	
Login	☒	☐	☐	Team 2
Shutdown	☒	☐	☐	Team 2
Minimize	☒	☐	☐	Team 2
Use Tools -> Options	☒	☐	☐	Team 2
Change Layout Settings	☒	☐	☐	Team 2
Perform Remote Actions	☒	☐	☐	Team 2
Operate Layout Tour	☒	☐	☐	Team 2
Operate CaseBuilder	☒	☐	☐	Team 2
Cameras	☐	☐	☐	
Microphones	☒	☐	☐	
Monitors	☒	☐	☐	
Speakers	☒	☐	☐	
PTZ	☒	☐	☐	
Alarm Management	☒	☐	☐	
Analytics	☒	☐	☐	
Admin Center	☐	☐	☒	
Login	☐	☐	☒	
Modify Global Settings	☐	☐	☒	
Install and Update License	☐	☐	☒	
Export Field Report	☐	☐	☒	
Perform Mass Export	☐	☐	☒	
Use Reporting Tool	☐	☐	☒	
Servers	☐	☐	☒	
Edge Devices Configuration	☐	☐	☒	
Scenes Configuration	☐	☐	☒	
Sites and Enterprises	☐	☐	☒	
Maps	☐	☐	☒	
Layouts	☐	☐	☒	
Camera Sequence	☐	☐	☒	
User Management	☐	☐	☒	
Alarms	☐	☐	☒	
Coverages, Profiles & Schedules	☐	☐	☒	
Plugins and Integrations	☐	☐	☒	
Mobile	☒	☐	☐	
Display video from mobile device	☒	☐	☐	Team 2

Figure 55 - Privileges Tab

To set the Privileges for this User Group (or this User):

- Check the radio buttons to set those functions (or groups of functions) to Allow or Deny.
 - **Allow** means that this user or group of users can perform this function or group of functions.
 - **Deny** means that the user or group of users cannot perform this function or group of functions.
 - If you click on the radio button for a group of functions (e.g. 'Alarm Management') then all the functions in that group are set to that value together.

10.2 Inheritance

To make it easier to set up Access Rights and Privileges for Users, Latitude implements **inheritance** of these parameters. If you set up a User Group, and specify Access Rights and/or Privileges for the Group, then all Users who become members of that group 'inherit' the same settings.


11 APPENDIX 1 - 'How to' Configuration Information

11.1 Tips and Tricks using the Latitude Interface

If you are new to Latitude, Welcome!


As you'll see, there is a lot of information to deal with, so we've put lots of 'smart' features in the interface - some from Windows, and some of our own, to help you to get around the very full screens.

Here are some for you to get started with.



11.1.1 Foldaway Bars

Foldaway Bars let you hide whole screen sections to provide maximum space for viewing details.




Foldaways Open - View more Panes

Foldaways Closed - View more Detail


11.1.2 Using 'Switch View' or clicking a node

When looking at items in the Navigation Tree or in Entity lists, there are some tools to help:

- Clicking to open or close **Nodes** in the tree




Nodes are closed - click on **+** to open




Node is open - click on **-** to close

- Using **Switch View** to toggle between a **Tree** or a **List**




Switch View - Tree view




Switch View - List view

11.1.3 Dialogs Display When Items are Selected

When a list is shown, the details are expanded as you select an entry.



With no entity selected, the data columns provide less detail




Once an item is selected, available data options and more detail display


Viewing **current Settings** and entering **new settings**



USEFUL TIP: Remember - you can use the [Foldaway Bars](#) to expand the pane and view more detail





Once items have been selected, you can view their current settings



Clicking on a current setting opens the dialog to update it

11.1.4 Search Bar Highlight mode

- Using Free Text **Search** to **List** or to **Highlight** Entities



Free Text Search - Only the Selected Items

Free Text Search - Highlight the Selected Items

11.2 Define Coverages from the System Settings View

A **coverage** defines a time span. Coverages (and combinations of coverages called "super-coverages") are commonly used as building blocks when configuring entities, events and actions.

The system comes with **always** and **daytime** predefined default coverages. Additional Coverages can be defined as **Create a Coverage**, or directly in the different Camera screen tabs.

A standard coverage defines time periods for each day of the week and has a start and an (optional) end date. A super coverage is a positive and negative combination of other coverages (including super-coverages) and is used to specify time periods that do not follow weekly schedules, such as holidays.

Note: When configuring coverages, start with standard coverages and then proceed to super-coverages, going from the simplest to the most complex.

11.3 Create a Coverage in System Settings

This section describes how to create a coverage in the system settings.

Follow these steps:

- From the **System Setting** view, right-click **Coverages** and select the **Add Coverage** or **Add Super coverage** options.




Figure 56 - Admin Center - Add Coverage

When you select **Add Coverage**, it opens the **Create Coverage** dialog. A predefined name is allocated to the Coverage, e.g. 'New Coverage n' (you can edit this to make a more meaningful name). The name is added to the list of defined Coverages.

- Use the same steps as in [Define a New Coverage from the Camera Screen](#) to define when the Coverage applies.
- Click **Save**  to save the new Coverage.

11.4 Choose an Existing Coverage from the Camera Screen

This section describes how to choose an existing coverage from the camera screen.

Follow these steps:


1. Click **+** to add a coverage to this field from those already defined in System Settings. The list of existing coverages displays.
2. Click on a coverage in the list to display the Days/Times when it is active. Use the **Switch View** button to view additional coverages.
3. When you have selected the coverage you wish to use, click **OK**.

11.5 Define a New Coverage from the Camera Screen

This section describes how to define new coverage from the camera screen.

Follow these steps:

1. In the **Video Settings**, **Picture Settings**, or **Recording Settings**, click . The **Create coverage** dialog displays.



The 'Create coverage' dialog box is shown with the following sections:

- Information**: Fields for Name and Description.
- Date Range**:
 - Date Range: Start date (Thursday, September 5, 2019) and End date (Friday, September 6, 2019).
 - Effective indefinitely: ☒
- Day and Time**: A grid for selecting days and times.

	00	01	02	03	04	05	06	07	08	09	10	11
Sunday												
Monday												
Tuesday												
Wednesday												
Thursday												
Friday												
Saturday												

Buttons: OK, Cancel

Figure 57 - Admin Center - Define a Coverage

2. In the **Create coverage** dialog, enter a new coverage name and add a description. By default, the new coverage begins on the current date, and is set to be **Effective indefinitely**. If required, use the drop-down to open a calendar work box, and set a different Start date.
3. If an end date is required, in the **End date** section deselect the **Effective indefinitely** option, use the drop-down arrow to open the second calendar work box, and set an end date.
4. In the **Day and Time** section, use the mouse to click-and-drag a rectangular area representing the days and times (in 15-minute increments) that make up the Coverage. If non-continuous times are required, hold down the **Ctrl** key while clicking and dragging the mouse. This allows multiple areas to be defined.
5. Click **OK** to save the Coverage.
When the new Coverage has been created, use the steps described above in [Choose an Existing Coverage from the Camera Screen](#) to apply it.

11.6 Create a Video Profile (using System Settings View)

Profiles are sets of values for related parameters used to simplify and expedite the configuration of cameras or other entities.

Table - Video Profile Types

Profile Type	Description
Video	Configures video-specific parameters such as frame rate, bit rate, resolution, and compression method (MJPEG, MPEG4, etc). Note: Default video profiles are predefined in the system for all cameras that are integrated with Latitude.
Picture	Configures image display parameters such as gain, brightness, etc.
Recording	Specifies recordings' lifespan as well as whether to store motion indications for the recordings.



TEMPLATE - For a particular camera, for each setting type (**Video** settings, **Picture** settings, and **Recording** settings), there can be only one profile per coverage.

11.7 Video Profile Parameters

Profiles are linked to coverages. It is possible to create one profile for each coverage. Latitude comes with a number of pre-Configured profiles, some of which are used when configuring default quality and recording schedules with the Quick Configuration Wizard.

The different profiles are usually added in the respective setting tabs of a camera in the Physical View (Video Settings and Picture Settings). When adding a coverage to a camera, a predefined profile can be selected from the drop-down list or a profile can be customized. The selected coverage and its profile appear in the **Summary** pane of the relevant tab of the camera entity.

Directly Access Generic Profiles

You can directly access generic profiles.

Do the following:

- To access generic Profiles directly, expand the **System Settings** drop-down menu in the Sidebar, and then select **Profiles**.

Add a Custom Video Profile

You can add a custom video profile.

Do the following:

- Right-click the **Profiles** branch in the **System Settings** root tree of the **View Selection** pane and select the **Add Video Profile** option.
The customized profiles are accessible via the Profile drop-down list of the relevant camera setting tabs.

When defining new profiles, each profile type has its own set of parameters, and is initially populated with default values.

11.8 Video Profile

The video profile enables you to create a name and description, and set various configuration settings such as bit-rate, frame rate, storage space, compression, etc.

Figure 58 - System Settings - Video Profile with Default Values

11.9 Create Schedules (using System Settings View)

Schedules are used to associate a **coverage** (“when”) to a **profile** (“how”) to applicable entities such as cameras and microphones (“what”).

The system uses the following schedule types:

- **Picture** – Advanced capability: Schedules are not normally used to control Picture Profiles.
- **Live Video Quality** – Enables you to set coverages during which different Live Video Quality Profiles are to be applied.

Note: For single-stream cameras, this schedule is used for both Live Viewing and Recording.

- **Recorded Video Quality** – Enables you to set coverages during which different Recording Quality Profiles are to be applied.

Note: This schedule type is only available for cameras with dual-stream capability.




Figure 59 - Camera that supports Dual streams

- **Recording** – The recording schedule sets coverages during which recording is required


The configuration panes for all schedules take the same basic form:

- The **General** tab is used to specify a coverage and profile. Choose your desired coverage and profile from their respective fields.
- The **Attached Schedule** tab is used to apply the schedule to entities. Use the arrow and double arrow buttons to move entities between the **Available Entities** and **Selected Entities** boxes.

It is possible to attach units to predefined schedules. The common procedure is to access the desired camera and select the desired coverage and profile directly in the different **Setting** tabs.

11.10 Create a New Schedule

This section describes how to create a new schedule.



Follow these steps:

1. From the **System Settings** view, right-click **Schedules** and select a **Add <type> Schedule** option.




Figure 60 - Admin Center - Add Schedule

The new schedule **General** tab opens with a default name **New <type> Schedule n**.




Figure 61 - System Settings - Add <type> Schedule - General

2. Do the following:
 - a. In the **Name and Description** section, enter a new name for the coverage, and if required, add a description.
 - b. In the **Configuration** section, use the drop-down arrows to select a **Coverage** and a **Profile** for this schedule, and enter a **Camera type**.
 - c. Open the **Attached Entities** tab, and in the **Attached Entities** section use the arrows to select which camera/s should be associated with this schedule.
3. Click the **Save** icon (💾) to save the schedule.

11.11 Configure Actions and Events

The **Actions** tab enables you to select an Event that can be sensed, and associate an Action that must be carried out when that event occurs.

Follow these steps:

1. From the **Actions** tab of any entity, you can open a list of the events that can originate from that type of entity.




Figure 62 - Configuring an Action

2. From the list of available events, right-click on the **Event** which you wish to use as the trigger for the action.
The list of available **Actions** is Displays.
3. Click on the required action.
Once an action is selected, it is added as an entry under the event in the Navigation tree, and a default Coverage of **Always** is associated with it.
You can choose a different coverage from the drop-down.
4. Complete the configuration of the action, selecting from the information provided in the **Action details** pane, and click the **Save** icon (💾).

11.12 Bind Encoders and Cameras

You can "bind" a TRK-101 or TRK-101-P encoder to a camera from the Latitude AdminCenter. Binding enables functionality such as providing Analytics on the camera scene, or allowing PTZ tracking of moving objects.

Binding Steps Summary (full description in the Help file)

The following procedure describes the binding steps.

Follow these steps:

1. Use the **Analytics** tab in the System/General Screen to show the available cameras in the system.
2. In the **Configure Security Settings** section, do the following:
 - a. Use the **Select** arrow to select the camera to bind to the Encoder in the **Available Cameras** section.
 - b. In the **Analytics Device IP** column, enter the Encoder IP address.
 - c. In the Connection Type column, use the drop down option to select the **Connection Type** details, and click 💾 to save the settings.
3. Use the Encoder's Web interface to configure the required Analytic settings.

11.13 System-Wide Events

Normally, events are tied to specific entities, and actions generated by them are only triggered when that event occurs for that specific entity. The system also allows for the definition of system-wide events – that is, events are recognized when they occur, regardless of the specific entity to which they are related.

The available system-wide events are listed in the iSOC Screen/Actions tab.




Figure 63 - Selecting a System-Wide Event

To configure a system-wide event, follow these steps:

1. Open the iSOC Actions tab, and right-click on the event which should initiate the Action. The list of available actions displays.
2. Select the required Action from those marked 'system-wide'.




Figure 64 - Configuring the Action associated with the System-Wide Event

3. Click on the selected **Action** to add it to the Event Tree.
If the action is not to be applied all the time, use a different **Coverage**.
4. Complete the fields required for this Action, and click the **Save** icon .

11.14 TLS - Setting up Encryption to/from Web Clients

TLS - Transport Layer Security

As more users take advantage of the Latitude Web Client, it becomes more important to protect the system from unauthorized access via Internet connections. Latitude allows the user to use standard Internet security infrastructure to protect communications between the System and any Web Clients. The user purchases a TLS Certificate from a trusted Certificate Provider, and installs it on their system. Once the certificate is loaded into the Latitude, the system encrypts all connections to and from Web Clients.

Summary of Required Steps:

(A full description of these steps is included in the Latitude Admin Center Help file.)

1. In consultation with you IT department, acquire a TLS Certificate and place it in the system.
2. Ports: The required ports for encrypted communications are set up by default. The IT department should confirm that there are no conflicts (and if required, suitable adjustments must be made.)
3. From the **System/General/IP Security** panel, follow the process to 'Load' the TLS Certificate.

12 APPENDIX 2 - Admin Center - User Interface Details

The default setting for the Admin Center opens the application at the [Dashboard](#) screen which provides a system status summary – from here you click on any of the buttons in the [Sidebar](#) on the left of the screen to navigate to the different filtered views of the [Main Screen](#), to the [Wizards](#) for specific tasks, or to the other [Applications](#) that are available.




Figure 65 - Admin Center Main Screen Workspace

Note: Access the online [Help](#) system at all times by clicking on the Help icon, , in the top right-hand corner of the screen. Help is context-sensitive, so whatever screen you are in, the Help system displays the details of the parameters relevant to that screen.

12.1 Main Screen

The Admin Center workspace is divided into the following sections:

- [Sidebar](#) - Provides access to specific system views and launches system applications.
- [Navigation Tree Pane](#) - Enables the user navigate to other system entities.
- [Configuration Pane](#) - Provides access to all the parameters of the entities making up the system. Any entity – a camera, an encoder, one of the system servers, or even the definition of a particular user - can be called up by selecting it in the Navigation Tree Pane.




Figure 66 - Admin Center - Main Screen Panes

12.2 Sidebar

The Sidebar provides the user quick access to filtered views of the system, and easy activation of common tasks.












Figure 67 - Admin Center Main Screen Sidebar

Click on any Sidebar component to select the corresponding view in the Selection and Configuration panes. (See table below).


Table - AdminCenter/Main Screen/Sidebar Components

Icon	Description
iSOC	Clicking on the System icon shows the Dashboard (i.e. the system summary)
Logical View	Shows a Navigation tree that organizes the software configurations and security “logical” entities into one view.
Physical View	Shows a Navigation tree that contains a systems and hardware-centric view

Icon	Description
System Settings	Provides access to System Configuration Sub Menu The drop-down arrow lets you access the following directly:
Video	Displays a filtered Logical View that only shows video related entities (i.e. Cameras and Monitors) The drop-down arrow lets you access the following directly:
Audio	Displays a filtered Logical View that only shows audio related entities (i.e. Microphone and Speakers), or gives access directly via the submenus The drop-down arrow lets you access the following directly:
Users and Groups 	Displays a filtered Logical View that only shows Users and User Groups), or gives access directly via the submenus The drop-down arrow lets you access the following directly: 
Servers 	Displays a filtered Physical View that only shows the Server related entities. Relevant sever pages can be accessed directly from the submenu. The drop-down arrow lets you launch applications directly from the Sidebar:

Icon	Description
	
Applications 	Opens submenu with Latitude-related Applications The drop-down arrow lets you access the following directly: 
Discovery 	Opens the Discovery tab in the Settings Area for adding Edge Devices to the system
Wizards 	Displays submenu for selecting Wizards that help guide the User through the steps of creating and configuring the system The drop-down arrow lets you access the following directly: 

Minimizing the Sidebar



Note:

The Sidebar can be minimized and re-opened by clicking on the 'Minimize' symbol.

12.3 Dashboard

The Dashboard provides a managerial snapshot on various system-wide activities and settings. By viewing the Dashboard, you can view the status and data of the different components managed via the AdminCenter. You can also quickly identify and repair inaccessible cameras by clicking on the highlighted text.

The Dashboard displays when the Latitude AdminCenter starts up, and click on the iSOC icon in the sidebar to display at any time.




Figure 68 Dashboard - the iSOC ‘Home’ Screen - Displays a System Summary

Dashboard information is organized in the following panes:

- Cameras
- Users
- Archivers and Storage
- Recorded Stream Quality
- Database Health
- License Information

Note: Deselect the **Display Dashboard at startup** option to not display the Dashboard on startup.

12.3.1 Camera Pane

This pane contains detailed data on the cameras currently defined in and attached to the system. Click each option to drill-down to a detailed list of cameras and their status.

You can display more information by clicking on the underlined words. A summary of the corresponding camera information displays:




Figure 69 - Dashboard - Cameras Pane

12.3.2 Users Pane

The Users pane lists the number of currently logged-on and defined users




Figure 70 - Dashboard - Users Pane

12.3.3 Archivers and Storage Pane

The Archivers and Storage pane details data on all Archivers, attached video devices, and currently defined storage. Click each option to drill-down to a detailed list of Archivers and cameras attached to the Archivers, and the storage units and their status.



Figure 71 - Dashboard – Archivers and Storage Pane

You can display more information by clicking on the underlined words. A summary of the corresponding Archiver and Storage information is shown:

Archivers				
Name	Cameras	CPU	Memory	Throughput
Main Archiver	6	4%	775.79 MB	105 KBps

12.3.4 Recorded Stream Quality Pane

The Recorded Stream Quality pane displays recording video quality profiles currently defined in the system.

Profile	Framerate	Bitrate	Resolution
Pro Elite - PAL H264 D1 Medium-High Video	12	512	D1
IOimage - MPEG4 (4CIF) Medium-High Video	25	2048	4CIF
Axis High MPEG4 / VGA Quality Video Profile	13	1410	E4
IOimage - MPEG4 (16CIF) Medium Video	30	990	VGA (640x480)

Figure 72 - Dashboard - Recorded Video Quality Pane

12.3.5 Database Health Pane

The Database Health pane displays database size, log size, and server status currently defined in the system.

Server	DB Size	Log Size	Status
Directory server	13.75 (MB)	11.22 (MB)	Connected
Main Archiver (LoggerDb)	9.19 (MB)	3.34 (MB)	Connected
Main Archiver (LoggerDb_Location)	5.13 (MB)	1.29 (MB)	Connected
Main Archiver (LoggerDb_Motion)	5 (MB)	1.28 (MB)	Connected

Valid entities: 474
Invalid entities: 0

Figure 73 - Dashboard - Database Health Pane

12.3.6 License Information Pane

The Latitude Directory Server holds all the license information for the installation. Licenses cover which components may be used and the number of servers, backup servers and clients that may be used.

You can see detailed information about the licenses currently activated for the system, including whether you are licensed, how many instances you may use (if applicable) and how many are currently in use.

The Activation Key and License Type are also shown.

License Information		
Feature	Feature Inf...	Usage
Active Directory integration	Supported	Not In Use
Add-on component	Unlimited	0
Case Builder	Supported	In Use
DSF connection	Unlimited	0
Failover Directory	Unlimited	0
Failover video channel	Unlimited	0
Global user	Unlimited	0
Keyboard connection	Unlimited	0
Latitude Lite	Not Supported	Not In Use
Mobile user	Unlimited	0
Activation Key: 1-DEC9-8F03-E060-7F56		
Feature Set: 6.2 ALL FEATURES		

Figure 74 - Dashboard - License Information Pane

12.4 Navigation Tree Pane




Figure 75 - Admin Center Main Screen – Navigation Tree Pane

12.4.1 View Dropdown - Navigation Tree Pane

The **View** drop-down enables you to select which system components to display in the Selection Tree.

Do this by selecting a value from the **View** drop-down box (or by clicking on a Sidebar button).

The available views are as follows:

View	Description
Logical View	Logical entities – Cameras, Control, Tile Layouts, User Groups, Users.
Physical View	Physical Configuration – Hardware and Server components, Edge Devices.
System Settings	System-related entities, such as Alarms, Global Schedules, etc.

12.4.2 Navigation Tree Tools



A set of tools is provided to assist you in managing the items displayed. These tools are particularly useful in larger installations, where the list of items in the Navigation tree can be very long.

Icon	Function	Description
	Refresh	Enables the user to refresh the view during editing.
	Grouping	Puts all the items in the Selection Pane into their categories. The grouping is alphabetic – i.e. all Cameras, Input Pin devices, Microphones, Output Pin devices, Speakers, User groups, etc. When you want to see all elements of a similar type, such as all Input Pin #1's, or all Microphones, this displays them together, rather than having to scroll through all elements looking for similar sub-components.
	Copy Configuration	(See Using 'Copy Configuration')
	Delete	Deletes the selected item.
	Add	Clicking on the pull-down provides quick access to a list of elements that can be added to the configuration. The items available in the list vary depending on the current view.
	Filter Tool	Pull-down provides quick access to a list of categories that can be used to filter the current view. The items available in the list vary depending on the current view. (available in the Logical, Physical and System Settings views. One or more filter criteria can be selected at a time. At the bottom of each list there are the general filter options – All, None or 'No filtering'.)




12.4.3 Selection Pane Tools –‘Add’ options depending on current view

Table - Selection Pane Tools –‘Add’ Options Depending on Current View


Add from Logical view

Add from Physical view

Add from Video View



Add from Audio view



Add from Users and Groups




12.4.4 Selection Pane Tools – ‘Filter’ options depending on current view

Table - Selection Pane Tools – ‘Filter’ options depending on current view

Filter from
Logical view

Filter from
Physical view

Filter from
System Settings view



12.5 Configuration Pane




Figure 76 - Admin Center Main Screen Configuration Pane Details

The selected entity details are shown grouped in **Tabs**, with each tab showing one or more **Panels**.

You can switch between tabs by clicking on the tab name at the top of the screen.

Click on the maximize and minimize panel icons (▾ ▴) on the relevant panel header bar to open and close panels.

12.5.1 Configuration Pane Tools



Icon	Function	Description
	Save	The Save button is enabled whenever you have edited the value of a parameter. Your change is only effective after clicking on the Save button.
	Undo	While editing, anytime <i>before</i> you click the Save button, you can click the Undo button to clear the changes you have made and revert to the current value.
	Back/Forward	These buttons navigate you through the tabs for this element.
	Collapse/Expand	These buttons open or close all panels in the current tab.
	Help	Opens the context-sensitive Help window.

13 APPENDIX 3 - License Information

13.1 License Components

Table - License Components

Feature	Comment
Active Directory Integration	Enables the option to integrate with Microsoft Active Directory (AD) - Supported / Not supported
Add-on Component	Number of permitted Add-On components -- Add-On component licenses will be provided by DVTEL with the purchase of engineering service integration modules
Case Builder	Enables the use of the Case Builder application - Supported / Not supported
DSF Connection	The Direct Show Filter connection - Supported / Not supported
Failover Directory	The number of failover directory servers in the system, not including the primary directory
Failover Video Channel	Number of supported camera scenes or analog monitor scenes for which the Archiver failover mechanism is licensed
Global User	Number of global user connection licenses
Keyboard Connection	Number of CCTV keyboards concurrently configured in the system
Latitude Lite	Enables the use of the Latitude Lite application, which is based on a single server, pre-loaded with the Latitude software, pre-licensed and pre-Configured, to provide a quick and smooth deployment at the customer premises - Supported / Not supported
Mobile User	Number of Mobile Users Licensed/Active
Mobile Video Feed	Number of Mobile Feeds Licensed/Active
Privacy Masking	Supported / Not supported
Redundant Channel	Number of supported camera scenes or analog monitor scenes
Reporting Tool	Licensed to use Pre-defined Reports - Supported / Not supported
SceneTracker Channel	Number of SceneTracker user connection licenses
SDK Connection	Number of logins to the Directory server from SDK applications
SNMP	Enables the administrator to send out SNMP traps to any 3rd party Network Management System and to Configure which Latitude events will be sent out as traps - Supported / Not supported
User Session	Number of concurrently active user sessions logged in to the Directory server

Feature	Comment
Video Channel	Number of supported camera scenes or analog monitor scenes
Virtual Video Channel	Number of supported matrix outputs
Web Client User	Number of concurrently active Web Client sessions logged in to the Directory server

13.2 Licensing the Failover Directory

The Failover Directory requires a separate license as it is installed on a machine with a different machine ID.

FLIR issues the necessary licenses on the Licensing Web server.

13.3 Failover Directory License File Installation

This section describes how to install the failover directory license file.

Follow these steps:

1. From the AdminCenter, on the System Settings Root — License General Page, click the Failover directory in the Directory Servers list.
2. Click Install License to install the license.
The **Install License** dialog displays.
3. Follow the same procedures as for activating a regular license, with the exception of using the Machine ID of the Failover directory.
See 2 [License your Latitude System](#).

Once the Failover Directory has been installed and created in the system, and has communicated with the primary directory, the details of the Failover Directory appear in the Directory Servers list on the System Settings Root/License/General screen.

There is no need to register the customer details since this is not the first activation.

14 APPENDIX 4 - Installation Overview

Full details of the installation process are provided in the version Release Notes. An overview of the procedure is included below.

14.1 Installation Prerequisites

Prior to the installation, verify that the `InstConfig.INI` file, which should be included in the installation CD or ZIP file, is available in the same directory as the installation executable file.

14.2 Installation Process

This section describes the installation process.

Follow these steps:

- 1) Insert the Latitude NVMS CD into your CD drive.
If the installation wizard does not begin automatically, browse the CD and double-click the **setup.exe** file.
If you have the install file on another medium, you can copy it (and the **Instconfig.INI** file) to your desktop and execute it from there.
Before the files are extracted, a message displays providing the installation cache files location, and warning the user that this folder must not be removed.
- 2) If prompted that your system requires a newer .NET and/or DirectX version, allow the wizard to install the necessary software on your computer, and accept the license agreement.
- 3) Select an installation folder and set the desired language to be used when working with the Latitude system.
- 4) Choose the type of Installation you require:
 - **Client Application Installation** - For a computer that is going to be used as a workstation (Only installs the Client Applications).
 - **Server Installation** - when the Latitude services are going to be spread over several computers. If you select this option, select the server that must be installed on this computer.
 - **All in One Installation** - When the Latitude services are going to be run on a single computer.
 - **Custom Installation** - Allows you to choose specific program features to install – (for advanced users).
- 5) Components requiring a database:
When installing a component that requires a database, select whether to install a new database or use an existing one.
For an existing database, specify the location and login fields.
- 6) Run the installation process.
- 7) For a new installation, select **Launch AdminCenter** on the **Installation Wizard Completed** screen, and then click **Finish**, to continue with the instructions to [License your Latitude System](#).

15 APPENDIX 5 - Terminology

The following are Latitude system commonly used terms:

Table - Latitude Terminology Table

Term	Description
AdminCenter	The client application that performs Latitude configuration tasks.
ControlCenter	The client application that is used by the operators who monitor the live video material, that handles the system alarms, locates and displays video clips of previous incidents, and prepares material for system export.
Edge Device	In the context of Latitude, an edge device is either an IP camera or a video encoder, and in general, any IP device that is managed by the system (other than the servers and client workstations).
Entity	Used to refer to any of the addressable edge devices that are connected to the Latitude network.
IP Camera	A CCTV camera that can be connected to the IP network and transmits digital video over the network rather than analog over coaxial cables.
iSOC	Intelligent Security Operations Center (iSOC). In Latitude Systems earlier than version 6.3, the default name for the 'root' of the Latitude System was iSOC.  The default name of the system is now System and this can be viewed in the Sidebar and at the top of all tree diagrams of the system.  The User can change the variable that is shown as the system name, but System remains the name on the system icon.
Latitude	The Network Video Management System (NVMS).
MJPEG	"Motion JPEG" and is a JPEG-based codec, used in the physical security environment to translate analog video from closed circuit television cameras into a digital stream.
MPEG4	A popular video compression method used in most digital CCTV systems. MPEG4 is the default Video compression in Latitude.
Network Switch	A computer networking device that connects network segments.
ONVIF	Open Network Video Interface Forum. The ONVIF specification defines a common protocol for the exchange of information between network video devices. It includes automatic device discovery, video streaming and intelligence metadata.

Term	Description
OSD	On Screen Display - The system can also provide various additional information called the On-Screen Display (OSD). This can include such parameters as the camera name, address, site name where it is located, date and time it was recorded, image resolution, etc.
Scene	A 'scene' is a logical entity attached to a physical port . Scenes are the basic elements that appear in a logical tree – such as in the Navigation Tree of the Control Center. A scene is composed of a set of definitions that Latitude applies to a physical device and particular port – for example, a camera, with information about the way it is attached – i.e. the port details.
Software Services	(or simply “services”) — Programs without a user interface, that run automatically, normally in the background. In Latitude, there are multiple services that act as the server side (back end) of the system, such as the Directory, the EDB and the Archiver.
Transport Layer Security (TLS)	Latitude supports encryption of communications between the Transcoder/s and Web Clients.
Video Encoder	A device that converts an analog video signal to digital video signal and transmits it over an IP network. In addition to providing a digital image, encoders often provide many of the 'smart' digital-camera-style facilities for analog cameras.



FLIR Systems, Inc.
6769 Hollister Ave.
Goleta, CA 93117
USA

PH: +1 805.964.9797
PH: +1 877.773.3547 (Sales)
PH: +1 888.747.3547 (Support)
FX: +1 805.685.2711

www.flir.com/security

Corporate Headquarters
FLIR Systems, Inc.
27700 SW Parkway Ave.
Wilsonville, OR 97070
USA

PH: +1 503.498.3547
FX: +1 503.498.3153

Document:
Latitude Admin Center User Guide
Version: 1.0
Date: December 30, 2024
Language: en-US